

INSTALLATION INSTRUCTIONS

Tools Needed

- Wrench •



1. Before beginning any work be sure to shut off the water supply.
2. Apply teflon tape to ends of both the hot and cold supply nipples.
Place valve body through holes in tub. Thread the large locknuts onto the other ends of the nipples and secure the shower set to the tub.
3.
 - a. For models 191-S and 195-S with for use with risers, assemble riser pipe to the riser coupling assembly on the spout by tightening the coupling nut. After hand tightening, fasten securely by using a wrench.
 - b. For model 205-S for use with handshower, place rubber washer into hose connection and connect the hose to top of valve body.
4. Turn on water supply.