

Lift Rod Style Pop-Up Drain Installation Instructions

CALIFORNIA FAUCETS RECOMMENDS THAT ALL PLUMBING PRODUCTS BE INSTALLED BY A LICENSED PROFESSIONAL

I INSTALLING POP-UP DRAIN

- Remove COLLAR (11) from pop-up assembly and apply SILICONE CAULK (12) (or equivalent) to underside of COLLAR (11)

CAUTION: Do not use or any oil base sealant that may damage finish

- Insert DRAIN BODY (17) from underside through sink DRAIN HOLE (13) & attach to COLLAR (11)
- Align BALL ROD HOLE (17a) toward rear of sink and firmly tighten FLANGE NUT (16) against FRICTION WASHER (15), MACK WASHER (14) and sink DRAIN HOLE (13)
- Remove TAILPIECE (18) from DRAIN BODY (17), apply thread SEALANT (19) to TAILPIECE (18) threads and tighten into DRAIN BODY (17)
- Insert STOPPER (20) into COLLAR (11) & rotate off-set HOOK (20a) to front of sink to accept BALL ROD (21)
- Remove spring CLIP (24) from BALL ROD (21)
- Place CONE WASHERS (23) on both sides of ball rod BALL (21a) with NUT (22) to backside
- Insert BALL ROD (21) into body BALL ROD HOLE (17a) and through off-set HOOK (20a)
- Tighten NUT (22), but allow BALL ROD (21) to freely move up and down
- Place STRAP (23) onto LIFT ROD (8) and tighten THUMB-SCREW (23a)
- Place one end of CLIP (24) onto BALL ROD (21), then STRAP (23), gently squeeze CLIP (24) and slide other end of CLIP (24) onto BALL ROD (21)
- Check proper operation of STOPPER (20) and adjust by sliding STRAP (23) on LIFT ROD (8) as necessary

